



DIRECTIONS FOR MIXING CALCIUM HYPOCHLORITE SHOCK

1. Fill a 5 gallon bucket full of water.
2. Slowly pour desired amount of shock into bucket of water. (Always add chlorine to water. Never add water to chlorine.)
3. Use a stick or piece of PVC pipe and stir mixture of shock and water thoroughly.
4. Let the bucket of mixture sit in a shaded area for about 20 - 40 minutes. (PLACE THE BUCKET IN AN AREA THAT IS AWAY FROM CHILDREN AND PETS.)
5. Pour only the liquid contents of the bucket into the pool. Pour as little of the granular substance at the bottom of the bucket into the pool as possible. This granular substance is not the chlorine. This is calcium and it will not dissolve in your pool. When this calcium is dumped into the pool, the pool usually becomes very cloudy.
6. Dispose of the calcium that is at the bottom of the bucket. It can be thrown in the garbage or a compost pile safely. Do not add water to the bucket and try to re-dissolve this calcium.
7. Wait until the chlorine level in your pool drops to 3.0 parts per million before swimming in the pool. (It is recommended to shock at night).



Quality Products and Dependable Service Since 1976

Pool World Inc. Mailing Address: P.O. 14927 • Spokane, WA 99214-0927

Couer d'Alene Store
235 W. Sunset Ave
Couer D'Alene, ID 83815
(208) 765-5220

Spokane Valley Store
13524 E. Sprague Ave
Spokane, WA 99216
(509) 928-6585
Fax (509) 928-9469

North Spokane Store
9111 N Country Homes Blvd
Spokane, WA 99218
(509) 466-8220

Central Spokane Store
5701 E. Sprague
Spokane, WA 99212
(509) 534-4833

Toll Free (800) 876-4340